DUAL per I-Core

DUAL per I-Core

Utilizzate Dual per trasformare I-Core in un avanzato programmatore monocavo

Caratteristiche | **Modelli** | **Specifiche** | **Documenti**

DUAL è il nuovo accessorio monocavo per il programmatore I-Core di Hunter. Progettato per dare a tutti la praticità ed efficienza della tecnologia monocavo, il sistema DUAL può gestire fino a 48 zone tramite un'unica coppia di fili su distanze fino a 2,3 Km. Le 48 zone possono essere tutte installate in un unico percorso o divise su più percorsi per sfruttare i tubi interrati. Richiedendo solo due fili, DUAL offre risparmi senza pari in termini di manodopera, cavi e denaro. Poiché è un accessorio dell'I-Core gli installatori beneficiano degli stessi vantaggi e delle stesse funzioni avanzate quali monitoraggio della portata in tempo reale, luci di avviso di problemi e stato direttamente sul frontalino, SmartPort® installato in fabbrica, sei lingue disponibili e un ampio display retroilluminato. I decodificatori Dual sono disponibili in versioni a una e due stazioni. Denominati Dual-1 e Dual-2, le versioni offrono la flessibilità necessaria per ogni installazione. Inoltre l'I-Core può gestire sia stazioni standard che monocavo in contemporanea.

- Modulo per impianti monocavo per programmatori I-Core
- Decodificatori disponibili in versioni a 1 e 2 stazioni
- Funzione di vibrazione per una facile identificazione dei solenoidi sul campo
- Moduli specifici contro sovratensioni DUAL-S per messa a terra dei percorsi monocavo
- Distanza massima del decodificatore sul percorso monocavo alla centralina: cavo 14AWG 1.500 m; percorso 12 AWG 2.300 m
- Decodificatori programmabili dalla centralina (senza numero seriale alfanumerico)
- Il display e la programmazione tramite pulsanti del modulo DUAL facilitano la programmazione dei decodificatori presso lo stesso programmatore
- I decodificatori DUAL possono essere programmati sul campo con la console Hunter ICD-HP. Non è necessario scollegare i decodificatori dal percorso monocavo
- Il modulo Dual visualizza sul proprio display lo stato e i dati diagnostici
- Può azionare fino a 48 stazioni miste tra convenzionali e monocavo, facilitando l'aggiornamento e l'ampliamento di sistemi esistenti
- Connettori stagni in dotazione per il collegamento al percorso monocavo dei decodificatori DUAL e DUAL-S.
- Numero di percorsi monocavo: 3

Include tutte le funzione del programmatore I-Core più quelle specifiche per i decodificatori. [1]

Decodificatori programmabili [2]

Console di programmazione per decodificatori senza fili ICD-HP [3]

Cavo per percorsi monocavo IDWire con doppia guaina [4]

Connettori impermeabili compresi [5]

Source URL (retrieved on *30/08/2015 - 11:42*): http://www.hunterindustries.com/it/product/programmatori/dual-i-core

Links:
[1] http://www.hunterindustries.com/it/node/5116
[2] http://www.hunterindustries.com/it/node/5166
[3] http://www.hunterindustries.com/it/node/5431
[4] http://www.hunterindustries.com/it/node/4946
[5] http://www.hunterindustries.com/it/node/5426
[6] http://www.hunterindustries.com/sites/default/files/BR_Dual_IT.pdf
[7] http://www.hunterindustries.com/sites/default/files/BR_Dual_dom.pdf
[8] http://www.hunterindustries.com/sites/default/files/BR_Dual_em.pdf
[9] http://www.hunterindustries.com/sites/default/files/BR_Dual_SP.pdf
[10] http://www.hunterindustries.com/sites/default/files/BR_Dual_FR.pdf
[11] http://www.hunterindustries.com/sites/default/files/BR_Dual_PT.pdf
[12] http://www.hunterindustries.com/sites/default/files/BR_Dual_GR.pdf
[13] http://www.hunterindustries.com/it/global
[14] http://www.hunterindustries.com/sites/default/files/DG_DecoderDesignGuide_it.pdf
[15] http://www.hunterindustries.com/sites/default/files/DG_DecoderDesignGuide_dom.pdf
[16] http://www.hunterindustries.com/sites/default/files/DG_DecoderDesignGuide_em.pdf
[17] http://www.hunterindustries.com/sites/default/files/DG_DecoderDesignGuide_sp.pdf
[18] http://www.hunterindustries.com/sites/default/files/DG_DecoderDesignGuide_fr.pdf
[19] http://www.hunterindustries.com/sites/default/files/DG_DecoderDesignGuide_gr.pdf
[20] http://www.hunterindustries.com/sites/default/files/dg_decoderdesignguide_tr.pdf
[21] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_it.pdf
[22] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_dom.pdf
[23] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_em.pdf
[24] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_SP.pdf
[25] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_FR.pdf
[26] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_PT.pdf
[27] http://www.hunterindustries.com/sites/default/files/BR_ICDHP_GR.pdf
[28] http://www.hunterindustries.com/sites/default/files/BR_ICD-HP_tk.pdf
[29] http://www.hunterindustries.com/sites/default/files/productimagepack_controller_i-core-dual.zip
[30] http://www.hunterindustries.com/sites/default/files/OM_Dual_IT.pdf
[31] http://www.hunterindustries.com/sites/default/files/OM_Dual_dom.pdf
[32] http://www.hunterindustries.com/sites/default/files/OM_Dual_em.pdf
[33] http://www.hunterindustries.com/sites/default/files/OM_Dual_SP.pdf
[34] http://www.hunterindustries.com/sites/default/files/OM_Dual_FR.pdf
[35] http://www.hunterindustries.com/sites/default/files/OM_Dual_PT.pdf
[36] http://www.hunterindustries.com/sites/default/files/OM_Dual_GR.pdf
[37] http://www.hunterindustries.com/sites/default/files/WS_ICore_DUAL.doc