Published on *Hunter Industries* (http://www.hunterindustries.com)

Read Article **Watch Video**

Node [1]

1. Push the button until the icon is displayed.
2. All 4 digits will be displayed representing the year. Use the or buttons to change the year. Press the button to proceed to setting the month.
3. All 4 digits will be displayed with the two digits on the left representing the month flashing. Use the or buttons to change the month. Press the button to proceed to setting the day.
4. Only the two digits on the right side will be displayed and flashing, representing the day. Press the or button to change the day. Press the button to proceed with changing the hour. Press the **right arrow (>)** button to proceed to setting the time.
5. The AM/PM/24 time setting is shown flashing. Press the or button to change the time setting to **AM**, **PM**, or **24-hour** time. Press the button to proceed to setting the hour.
6. All 4 numbers are shown with the two numbers on the left flashing, representing the hour. Use the or buttons to change the hour. Press the button to proceed to setting the minutes.
7. All 4 numbers are shown with the two numbers on the right flashing, representing the minutes. Use the or buttons to change the minutes. Pressing the button will advance to the year setting at step **#2**.

Installation Details, Installation Procedures

Rate this Article:

No votes yet

Source URL (retrieved on *27/08/2014 - 08:36*): http://www.hunterindustries.com/support/node-setting-date-and-time

Links:
[1] http://www.hunterindustries.com/irrigation-product/controllers/node
[2] http://www.hunterindustries.com/videos/node-setting-date-and-time
[3] http://www.hunterindustries.com/javascript%3Awindow.history.back%28%29%3B
[4] http://www.hunterindustries.com/videos/search
[5] http://subsite.hunterindustries.com/videos/mov/NODE_date-time_converted.mov
[6] http://subsite.hunterindustries.com/videos/wmv/NODE_date-time_converted.wmv