

DETAIL LEGEND:

- 1) TTS800-E POP-UP ROTOR, ELECTRIC VALVE-IN-HEAD
- 2) SOLENOID ASSEMBLY INSIDE TTS COMPARTMENT
- 3 HUNTER SWING JOINT ASSEMBLY (HSJ). INSTALL SWING JOINT LAY ARM AT 30°- 45° ANGLE TO THE LATERAL LINE.
- 4) LATERAL LINE FITTING PER PLAN.
- 5) LATERAL LINE PER PLAN. SOIL DEPTH PER PLAN.
- 6) 1½" [40 mm] MALE ACME

- 7) WIRE SPLICE IN TTS COMPARTMENT
- 8) WIRE TO SOLENOID WIRES
- 9) CONTROL WIRE
- (10) FINISHED GRADE



NOT TO SCALE REV: 2019-06-24