



Published on *Hunter Industries* (<http://www.hunterindustries.com>)

[Home](#) > What should I check if the controller has no display?

Products: [X-Core](#), [XC](#), [Pro-C](#), [I-Core](#), [ICC](#) [5]

Topics:

- [FAQs, Troubleshooting](#)

First, make sure there is power to the controller's outlet. Use a test lamp or any other 110VAC device to determine if there is voltage at the outlet. If there isn't power there, or if you have a controller that is hard wired, check the circuit breaker at the main breaker box.

Caution: High voltage testing on the transformers primary power side should only be done by a professional electrician or irrigation contractor.

If you have power at the outlet, the next thing to check is the transformer output. Use a voltmeter to check the voltage either on the two transformer wires or at the two AC screw terminals on the controller. The transformer should have an output in the range of 24VAC to 28VAC.

If the wall outlet has 110VAC and the transformer has no voltage output, you need to replace the transformer.

If you have voltage at both the wall outlet and the transformer output and you still have a blank display, try cycling the power on the controller. To cycle the power on the controller:

1. Remove the 9-volt battery.
2. Remove power by unplugging the transformer from the wall outlet or by turning off the circuit at the breaker box.
3. Wait 4-5 minutes.
4. Plug the controller transformer back into the electrical receptacle, or turn the breaker panel switch back on.



[6]

If this doesn't restore the display, the controller will need to be replaced.

Rate this Article:



' + 'ipt>'); //-->

- [Resources](#)
- [Product Catalogue and Parts List](#)
- [Video Library](#)
- [Document Library](#)
- [Site Study Library](#)
- [Online Training](#)
- [Support Library](#)
- [International Shipping](#)
- [Privacy Policy](#)
- [Corporate](#)
- [Careers](#)
- [California Supply Chains Act](#)
- [Hunter Family of Companies](#)
- [FXL Lighting](#)
- [Hunter Custom Molding](#)

Source URL (retrieved on 01/12/2015 - 00:07): <http://www.hunterindustries.com/en-metric/support/what-should-i-check-if-controller-has-no-display?source=lang&from=en&to=en-gb>

Links:

- [1] <http://www.hunterindustries.com/en-metric/irrigation-product/controllers/x-core>
- [2] <http://www.hunterindustries.com/en-metric/irrigation-product/discontinued-models/xc>
- [3] <http://www.hunterindustries.com/en-metric/irrigation-product/controllers/pro-cr>
- [4] <http://www.hunterindustries.com/en-metric/irrigation-product/controllers/i-corer>
- [5] <http://www.hunterindustries.com/en-metric/irrigation-product/discontinued-models/icc>
- [6] http://www.hunterindustries.com/sites/default/files/null/controllers_proc_04.png