


Products: [SRV](#),^[1]

[PGV](#),^[2]

[ICV](#),^[3]

Topics: FAQs, Troubleshooting

Simply twist the solenoid on the valve counter clockwise 1/4 turn to 1/2 a turn. To shut off the valve, twist the solenoid clockwise until it is snug on the valve.



[4]

Rate this Article:



Average: 5 (8 votes)

Related Links

Source URL (retrieved on 01/26/2015 - 15:38): <http://www.hunterindustries.com/support/how-do-i-manually-open-zone-control-valve-without-using-controller>

Links:

[1] <http://www.hunterindustries.com/irrigation-product/discontinued-models/srv>

[2] <http://www.hunterindustries.com/irrigation-product/valves/pgv>

[3] <http://www.hunterindustries.com/irrigation-product/valves/icv>

[4] http://www.hunterindustries.com/sites/default/files/ts_icv_labeled-diagram.jpg