

HUNTER IMMS CONTROLLER INTERFACE ①

CONDUIT AND FITTINGS PER LOCAL CODE ②


HUNTER ICC-SS OR ICC-M CONTROLLER ③

CONDUIT TO SENSOR:  
RAIN/FREEZE/FLOW-CLIK ④

JUNCTION BOX ⑤

CONDUIT FOR REMOTE CONTROL VALVE WIRING ⑥

CONDUIT AND FITTINGS TO POWER SOURCE. INSTALL PER LOCAL CODE 7



## ⑧ CONTROLLER MODULE AND WIRING PANEL

18/5 CABLE FROM CONTROLLER  
INTERFACE TO CONTROLLER, MAX CABLE  
FROM CONTROLLER TO CONTROLLER  
INTERFACE NOT TO EXCEED 1.8m.

⑩ GCBL CABLE FROM CONTROLLER  
INTERFACE TO SITE INTERFACE

⑪ MOUNT CONTROLLER AND CONTROLLER INTERFACE FIRMLY TO INTERIOR OR EXTERIOR WALL PER LOCAL CODES.

# ICC WITH CONTROLLER INTERFACE

✕

SCALE: 1:12

## Number: IRRIGATION DETAIL