



LEGEND:

- ① AIR RELIEF VALVE
- ② FINISHED GRADE
- ③ 1/2" FPT X 1/2" FPT PVC ADAPTER
- ④ IH RISER
- ⑤ FILTER FABRIC
- ⑥ PVC LATERAL PIPE
- ⑦ BRICK

NOTES

AIR RELIEF VALVE TO BE INSTALLED AT OPTIMAL HIGHEST POINT FROM CONTROL ZONE KIT. MULTIPLE AIR RELIEF VALVES MAY BE NEEDED TO ACCOMMODATE DIFFERENCES IN GRADE.



AIR RELIEF VALVE - IH RISER

Hunter HM.ARV.03

NOT TO SCALE