



**LEGEND:**

- ① PUMP START RELAY (PSR) PER PLAN
- ② CONDUIT TO PUMP
- ③ IRRIGATION CONTROLLER PER PLAN
- ④ ADJACENT SURFACE TO MOUNT CONTROLLER AND PUMP START PER PLAN
- ⑤ CONDUIT TO PUMP START RELAY
- ⑥ JUNCTION BOX AS PER CODE

XX
**PUMP START RELAY**  
**Hunter** C.PSR.01

NOT TO SCALE