Published on *Hunter Industries* (http://www.hunterindustries.com)

Products: EC [1]
Topics:

- Adjustment, FAQs

Hunter's EC controller comes with an **Interval Watering** feature. This Interval feature is set under the **Water Days** dial position on the controller. **Interval Watering** is a feature that allows you to select the number of days to pass before the next watering day.

Setting Interval Watering

With this option you can select interval watering from 1 to 31 days.

1. Turn the dial to the Water Days position.
2. Press button until the cursor is flashing on the day 7.
3. With the number flashing on day 7, press the button once more until the Icon appears (INTERVAL ICON) and a flashing 1 appear in the display.
4. Press the or button to select the number of days between watering days (1 to 31).

Example:

An interval of 3 will cycle the program once every three days and proceed to water on every third day from there on out. An interval of 1 is every day and an interval of 2 will water every other day. The controller will water the selected program at the next Start Time and will then water at the interval programmed.

Resources

[2]
EC OWNER'S MANUAL
[2]

Rate this Article:

' + 'ipt>'); //-->

- Resources
  - Product Catalogue and Parts List
  - Video Library
  - Document Library
  - Site Study Library
  - Online Training
- Support Library
  - International Shipping
  - Privacy Policy
- Corporate
  - Careers
  - California Supply Chains Act
- Hunter Family of Companies

- FXL Lighting
- Hunter Custom Molding

Source URL (retrieved on *01/12/2015 - 12:36*): http://www.hunterindustries.com/en-metric/support/how-do-i-program-interval-days-my-ec-controller

Links:
[1] http://www.hunterindustries.com/en-metric/irrigation-product/discontinued-models/ec
[2] http://www.hunterindustries.com/sites/default/files/OM_EC_EM.pdf
[3] http://www.hunterindustries.com/sites/default/files/OM_EC_DOM.pdf
[4] http://www.hunterindustries.com/sites/default/files/OM_EC_SP.pdf
[5] http://www.hunterindustries.com/sites/default/files/OM_EC_IT.pdf
[6] http://www.hunterindustries.com/sites/default/files/OM_EC_FR.PDF
[7] http://www.hunterindustries.com/sites/default/files/OM_EC_PT.pdf
[8] http://www.hunterindustries.com/sites/default/files/OM_EC_GR.pdf
[9] http://www.hunterindustries.com/en-metric/global