Published on *Hunter Industries* (http://www.hunterindustries.com)

Products: ICC [1]
Topics: FAQs, Installation Procedures, Troubleshooting

STEP ONE



[2]

The first step when installing a new front panel on a modular controller is to be sure power has been completely removed from the controller.

STEP TWO



[3]

After power has been removed, locate the front panels door tab on the top right of the panel.

STEP THREE

[4]

Pull the panel open just as you did with the controllers front door.

STEP FOUR

[5]

Locate the grey ribbon cable connected to the back of the face panel.

STEP FIVE

[6]

Carefully pull the plastic part of the ribbon cable out of the front panel. Ribbon cables can become corroded over time and after heavy abuse can tear or rip, be careful when

STEP SIX

[7]

Now that the front panel is removed from the power modules ribbon cable you can hinge the panel out starting with the top corner. Pushing up on the case's tab can make

removing the ribbon cable.

removal a little easier, as pictured here with the installer's right hand.

STEP SEVEN


[8]

The panel is now ready for removal. To install the new panel repeat these steps backwards, make sure not to bend any pins when plugging the ribbon cable into the new panel.

Resources

[9]
ICC OWNER'S MANUAL
[9]

Rate this Article:

No votes yet

Related Links

Source URL (retrieved on *04/09/2015 - 23:27*): http://www.hunterindustries.com/en-metric/support/how-do-i-replace-front-panel-my-hunter-icc-controller

Links:
[1] http://www.hunterindustries.com/en-metric/irrigation-product/discontinued-models/icc
[2] http://www.hunterindustries.com/sites/default/files/ts_icc_1.jpg
[3] http://www.hunterindustries.com/sites/default/files/ts_icc_2.jpg
[4] http://www.hunterindustries.com/sites/default/files/ts_icc_3.jpg
[5] http://www.hunterindustries.com/sites/default/files/ts_icc_4.jpg
[6] http://www.hunterindustries.com/sites/default/files/ts_icc_5.jpg
[7] http://www.hunterindustries.com/sites/default/files/ts_icc_5_0.jpg
[8] http://www.hunterindustries.com/sites/default/files/ts_icc_7.jpg
[9] http://www.hunterindustries.com/sites/default/files/OM_ICC_DOM.pdf
[10] http://www.hunterindustries.com/sites/default/files/OM_ICC_SP.pdf
[11] http://www.hunterindustries.com/sites/default/files/OM_ICC_IT.pdf
[12] http://www.hunterindustries.com/sites/default/files/OM_ICC_FR.PDF
[13] http://www.hunterindustries.com/sites/default/files/OM_ICC_PT.pdf
[14] http://www.hunterindustries.com/sites/default/files/OM_ICC_GR.pdf
[15] http://www.hunterindustries.com/sites/default/files/om_icc_ru.pdf
[16] http://www.hunterindustries.com/sites/default/files/manual_icc_ar.pdf
[17] http://www.hunterindustries.com/en-metric/global