Published on *Hunter Industries* (http://www.hunterindustries.com)

Node

Node

Controle Confiável através de Pilha Sem Necessidade de Ligação Elétrica

Para locais isolados, áreas com alimentação restrita ou necessidades específicas, o Node da Hunter é a solução inteligente e confiável. O Node é instalado em uma válvula de solenóide de forma rápida e fácil, e sem parafusos, orifícios ou fios adicionais. A construção sólida e o exterior impermeável da unidade garantem o funcionamento no difícil ambiente da caixa de válvula. O Node funciona com uma ou duas pilhas de 9 V e fornece alimentação de série ou prolongada ao longo da estação. Juntamente com uma confiabilidade excepcional, o Node inclui uma tela LCD de programação fácil e a capacidade de controlar uma Válvula Mestre, e utiliza a programação de controlador de série da Hunter com 3 programas e 4 horas de início por programa. O conjunto de opções de programação e a confiabilidade robusta tornam o Node um controlador de irrigação compacto mas poderoso com a flexibilidade da alimentação a pilha.

Características | **Modelos** | **Especif.** | **Recursos** | **Suporte**

- Funciona a pilhas
- Número de estações: 1, 2, 4 e 6
- Tipo: Fixo
- Modelo: Externo
- Programas independentes: 3
- Horas de início por programa: 4
- Tempo de execução máximo da estação: 6 h
- Aceita uma ou duas pilhas de 9V para duração prolongada
- Funcionamento de válvula mestre (disponível nos modelos de 2, 4 e 6 estações)
- O Kit de Painel Solar SPNODE elimina a necessidade de pilhas e proporciona o funcionamento sem manutenção
- Desligar programável
- Ciclo manual
- Comprimento de cabo de solenóide até 30 m (18 AWG)
- Período de garantia: 2 anos

Kit Painel solar compatível com Node [1]

Easy Retrieve™ [2]

Regulação sazonal global [3]

Compatibilidade de sensores [4]

Indicador de carga [5]

Corpo impermeável (WVC) [6]

Source URL (retrieved on *21/08/2014 - 18:15*): http://www.hunterindustries.com/pt/product/controladores/node

Links:
[1] http://www.hunterindustries.com/pt/node/12211
[2] http://www.hunterindustries.com/pt/node/12101
[3] http://www.hunterindustries.com/pt/node/12136
[4] http://www.hunterindustries.com/pt/node/12306
[5] http://www.hunterindustries.com/pt/node/12051
[6] http://www.hunterindustries.com/pt/node/12396
[7] http://www.hunterindustries.com/sites/default/files/BR_Node_PT.pdf
[8] http://www.hunterindustries.com/sites/default/files/BR_Node_dom.pdf
[9] http://www.hunterindustries.com/sites/default/files/BR_Node_EM.pdf
[10] http://www.hunterindustries.com/sites/default/files/BR_Node_SP.pdf
[11] http://www.hunterindustries.com/sites/default/files/BR_Node_IT.pdf
[12] http://www.hunterindustries.com/sites/default/files/BR_Node_FR.pdf
[13] http://www.hunterindustries.com/sites/default/files/BR_Node_GR.pdf
[14] http://www.hunterindustries.com/sites/default/files/br_node_tk.pdf
[15] http://www.hunterindustries.com/pt/global
[16] http://www.hunterindustries.com/sites/default/files/productimagepack_controller_node.zip
[17] http://www.hunterindustries.com/sites/default/files/OM_NODE_PT.pdf
[18] http://www.hunterindustries.com/sites/default/files/OM_NODE_dom.pdf
[19] http://www.hunterindustries.com/sites/default/files/om_node_em.pdf
[20] http://www.hunterindustries.com/sites/default/files/OM_NODE_SP.pdf
[21] http://www.hunterindustries.com/sites/default/files/OM_NODE_IT.pdf
[22] http://www.hunterindustries.com/sites/default/files/OM_NODE_FR.pdf
[23] http://www.hunterindustries.com/sites/default/files/OM_NODE_GR.pdf
[24] http://www.hunterindustries.com/sites/default/files/OM_NODE_tk.pdf
[25] http://www.hunterindustries.com/sites/default/files/om_node_he.pdf
[26] http://www.hunterindustries.com/pt/printpdf/product/controladores/node?solrsort=sort_label%20asc#node_product_full_group_support_tab
[27] http://www.hunterindustries.com/pt/printpdf/product/controladores/node?solrsort=is_rating%20asc#node_product_full_group_support_tab
[28] http://www.hunterindustries.com/pt/support/como-reiniciar-o-controlador-da-hunter