

Products: I-90 [1]

Topics: Installation Procedures

STEP ONE



[2]

The I-90 turf cup kit attaches to the top of the rotors riser assembly.

STEP TWO



[3]

First you will need to gain access below the rubber cover, removing the phillips head screw will allow for this.

STEP THREE



[4]

Remove phillips screw.

STEP FOUR



[5]

After the cover is exposed it's as simple as installing the new turf cup.

STEP FIVE



[6]

Make all necessary arc setting adjustments

STEP SIX



[7]

Screw the phillips screw tightly.

prior to installing the turf cup. Future arc setting changes will require removal of the turf cup.

STEP SEVEN



[8]

STEP EIGHT



[9]

Once the turf cup is installed on the rotor's top you can now slide the rubber cover over the whole head.

The I-90 is now ready for turf to be installed into its new addition.

Rate this Article:



No votes yet

Related Links

Source URL (retrieved on 06/03/2015 - 01:31): <http://www.hunterindustries.com/en-metric/support/how-do-i-install-i-90-turf-cup-kit>

Links:

[1] <http://www.hunterindustries.com/en-metric/node/221>

[2] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_1.jpg

[3] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_2.jpg

[4] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_3.jpg

[5] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_4.jpg

[6] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_5.jpg

[7] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_6.jpg

[8] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_7.jpg

[9] http://www.hunterindustries.com/sites/default/files/ts_i-90_turf_cup_8.jpg