



PARKING LOT MULTIPLE ISLAND TIPS

SCALE: 1" = 1'-0"

Hunter IRRIGATION DETAIL

NOTES:

1. SIZE EMITTER FLOW AND SPACING BASED ON PLANT AND SOIL TYPE.
2. ROW SPACING OF PLD TUBING BASED ON PLANT AND SOIL TYPE.
3. STAKE TUBING DOWN EVERY 5' AND WITHIN 1' OF ALL FITTING OUTLETS
4. DO NOT EXCEED VELOCITY OF 5 FPS WITHIN TUBING, IF SIZE OF DRIP AREA CREATES VELOCITIES GREATER THAN 5 FPS USE STANDARD LATERAL PIPE TO CREATE SUPPLY HEADER FOR THE DRIP AREA.
5. INSTALL FLUSH VALVE AT POINT FURTHEST FROM SUPPLY POINT.
6. THOROUGHLY FLUSH LATERAL AND DRIPLINE PRIOR TO FINAL CONNECTIONS
7. TEST DRIP LINE FOR PROPER OPERATION PRIOR TO COVERING.